



MASTER AUDIO VISUAL INTERFACE SYSTEM (MAVIS)

The MAVIS is a 6 input tone generator which generates customised tones and alerts to inform hospital staff of the priority of active nurse calls. The device is connected to multiple speakers so that the tones can be heard in various parts of the facility.



Technical Data	
Part Number	MAVIS
Ambient Temperature	0 – 50 °C (20-90% RH non condensing)
Storage temperature range	-10 – 60 °C (10-95% RH non condensing)
Type of protection	IP 31
Material	Metal Rack
Colour	Blue
Fixing / mounting	Rack Mount
Dimensions	L: 455mm W: 205mm D: 45mm
Weight	Approx. 2800g
Power Option 1 (Europe VDE DIN)	24V DC compliant with EN60601-1-2
Power option 2 (USA, AU and Asia UL1069)	24V DC compliant with UL1069

Features:

- 6 different tones available
- ▶ Rack mountable 1RU enclosure for simple installation
- Master volume control
- Individual volume control for every tone
- Custom tones can be created
- Attenuator override output at nurses' station enabling day/night mode
- Connects via Cat 5 to CarePlus™ CCM
- Crisp clear tones for alarm events
- Outputs:
 - 6W 8 Ohms output

Part No.	Description
MAVIS-1	Master Audio Visual Integration System (MAVIS) 1RU with AS3811 Tones
MAVIS-2	Master Audio Visual Integration System (MAVIS) 1RU with EMG-SA Reverse Tones (Sedco tones)
MAVIS-3	Master Audio Visual Integration System (MAVIS) 1RU with Custom Tones

The MAVIS is UL1069 and DIN 0834 certified, and meets AS3811.



AUTHORISED DISTRIBUTOR



USA office:

1000 N West Street, Suite 1200 Wilmington Delaware 19801 t: +1 302-295-4845 e: info.usa@niq-health.com Europe / UK office:

16 Upper Woburn Place London WC1H 0AF t: +44 (0)20 7193 0072 e: info.euorpe@niq-health.com Australian office:

Unit 2 / 3 King Edward Road Osborne Park, Perth Western Australia 6017 t: +61 8 9242 7407 e: info.aus@niq-health.com